TABLE OF CONTENTS

Before driving	Information on the hybrid system and adjusting and operating features such as door locks, mirrors, and steering column
When driving	Driving, stopping and safe-driving information
Interior features	Air conditioning and audio systems, as well as other interior features for a comfortable driving experience
Maintenance and care	Cleaning and protecting your vehicle, performing do-it-your- self maintenance, and maintenance information
When trouble arises	What to do if the vehicle needs to be towed, gets a flat tire, or is involved in an accident
Vehicle specifications	Detailed vehicle information
For owners	Reporting safety defects for U.S. owners, and seat belt and SRS airbag instructions for Canadian owners
Index	Alphabetical listing of information contained in this manual
	When driving Interior features Maintenance and care When trouble arises Vehicle specifications For owners